

Installation Instructions for the Manufacturer's declaration Power reduction 50SHT / 50SHT-S

- Establish a connection with your mobile device and the inverter and start the MaxLink APP.
- Switch to SETTING.
- Choose Settings.
- Log in to *Change User* with the password «admin».
- Slide the screen upwards and click on Power Reduction.
- Enter the value of the maximum power in watt and press OK.
- Press on Standard Code and select the Standard Code there.
- Change the user password and write it down.
- Wait until the inverter goes into operation and check the function on the start page of the MaxLink APP.
- Now close the APP and disconnect from the inverter's WiFi.

